

















## Replacement parts



	Koodi	Description
	B00519A	Hit indicate place, white + screw for fastening
	B00722A	Preparedness plate, red +screw for fastening
	B00214A	Hit plate, black
	B00386B	Shaft for the hit plate +lock rings
	B00099A	Pull spring, big
	B00100A	Pull spring, small

	Koodi	Description
	B00388A	Bow for the lift iron +locking screw
	B00097A	Wire cable
	B00385A	Chain for the lift iron including adjustment part
	B00389B	Bearing +adjustment part and fastening parts
	B00377A	Stand/ prone holder with fasteners
	B00263A	Pull rope for resetting the target from 50 meters distance



	Koodi	Description
	B00387A	Rubber for the target holder including fastening parts
	B00691B	STANDING/PRONE SIGNAL PLATE